

000000000000000000000000




FIG. 1

FIG. 2




FIG. 3 FIG. 4




FIG. 3




FIG. 4

130
120
504
516
510
114
PAD
PROCESSOR
POWER
ENABLE
326
424
320
436
ENABLE
MICROCONTROLLER




FIG. 5

TELETYPE 504




FIG. 6

504




FIG. 7